

Polttopuita löytyy pihassa olevasta lukitusta varastosta.

- Avaa savupelti hormista vetämällä nupista ulospäin, niin pitkälle kuin se tulee.
- Laita takkakytkin päälle (löytyy seinältä, tv:tä vastapäätä, käytävän toiselta puolelta)
- Varmista että ilmanohjausvipu (tuhkaluukun alapuolella) on käännetty vasemmalle.
- Tuhkaluukkua ei saa avata sytyttämisen ajaksi eikä takan ollessa käytössä.
- Laita puut takan pohjalle siten että ne eivät ylitä takalevyssä olevaa MAX-merkkiä.
- Sytytä puut ja anna tarvittaessa oven olla hieman raollaan aluksi. Kun puut palavat hyvin, voit sulkea luukun. Voit käyttää sytykkeenä sanomalehteä tai sytytyspaloja.
- Älä avaa takan luukkua ennen kuin takassa on tasainen hiillos. Luukkua avatessa kesken palamisen, voi palavia puita pudota takasta.
- Voit lisätä puita takkaan lisää, kuitenkin vain MAX- merkkiin saakka. Sulje luukku.
- Kun puut ovat palaneet loppuun eikä takassa ole enää punaisia kekäleitä, voit sulkea hormin pellin.

VARMISTA, ETTEI TAKASSA OLE YHTÄÄN PALAVAA/ PUNAISTA KEKÄLETTÄ!

- Huomioi, että takan pinnat ja luukun kahva tulevat erittäin kuumiksi. Luukun avaamiseen voit käyttää takkasetissä olevaa hanskaa.
- Älä jätä lapsia yksin takan kanssa.

Firewood can be found in the locked storage house outside.

- Open the fireplate in the flue by pulling it out by the knob as far as you can.
- Turn on the fire switch on the wall (across from the tv on the other side of the corridor).
- Make sure that the air control lever below the ash pan is pulled to the left.
- The ash pan must not be opened when starting a fire or when the fire is burning.
- Place firewood in the hearth, but don't go over the MAX marking on the back wall of the fireplace.
- Light the firewood and keep the door slightly ajar at first, if necessary. Once the fire gets going, close the door. Newspaper or firelighters can be used as kindling.
- Do not open the fireplace door before there are only embers left. If you open the door any earlier, burning wood may fall out.
- You may now add more wood to the fireplace, but remember to stay below the MAX marking. Close the door.
- Once the fire has completely gone out and there are no more glowing embers, close the fireplate.

MAKE SURE THAT THERE ARE NO GLOWING EMBERS IN THE FIREPLACE!

- Please note that the surface and the door handle of the fireplace become very hot. Use the glove provided to open the door.
- Never leave children unattended near the fireplace.