Fireplace

FIREPLACE IGNITION

- * Turn on the air conditioning fireplace setting before lighting from the switch on the wall next to the fireplace. Close the cooker hood.
- * Open the damper (smoke damper) by pulling out the knob and the ignition damper by turning the handle at an angle.
- * Before lighting, check that the grate is clean and that the ashtray is not full. (You can empty the cold ash into a metal container next to the grill outside the cottage.)
- * Leave the ashtray in a small gap.
- * Put a few firewoods in the fireplace. Firewoods must be at least 10 cm away from the glass door of the fireplace.
- * Light a fire in the fireplace.
- * When the firewoods are burning properly, you can add more firewood in a fireplace. Burn up to two additions of firewoos for a day in the fireplace. Overheating and oversized nests will damage fire surfaces and fireplace structures.
- * If you want to burn fire long time and enjoy the fire, add only a few firewood at a time. Do not exceed the permitted amounts of firewood's per heating session.
- * You can adjust the ventilation in the fireplace by opening the ashtray. The ventilation must never be adjusted with the fireplace damper.
- * 5 MINUTES FROM THE IGNITION CLOSE THE IGNITION SHELL by turning the damper handle straight. There is a risk of fire if the damper is kept open for longer periods during combustion!
- * Keep the fireplace door closed during use.

STOPPING THE HEATING

- * When the last firewoods have burned to the charcoal stage, use the fireplace tool to pull the charcoal over the grate.
- * Turn over charcoal a couple of times until charcoals are burned out (no glowing clumps).
- * Close the ashtray and damper.
- * If you suspect a danger of carbon monoxide, leave the damper slightly open. Remember! Carbon monoxide is an odorless, tasteless and colorless gas!

PLEASE NOTE

- * The fireplace is not intended for incineration. Do not use liquid fuel for ignition.
- * During heating and for a long time afterwards, the oven surfaces may be hot. The surfaces are hottest after the dampers have been closed.
- * Do not leave the fireplace unattended during heating.
- * Never leave children near a burning fireplace without adult supervision.
- * Do not store objects made of combustible material on or near the fireplace.
- * Do not empty warm or hot ash from the ashtray.
- * There are more firewood in storage at the yard.